

# Food Tracker®

# Thermocouples

Thermocouples are supplied with water tight connectors and gold plated connections to provide IP67 rating of the logger and guarantee reliability and accuracy in the most hostile of environments (steam/water/condensation, etc.). Thermocouples can be mixed and matched and interchanged. By selecting the appropriate thermocouple(s), the same unit can be used to monitor multiple different processes and products, maximizing its effectiveness for all your food processes.

Thermocouple cable lengths can be customized to match the exact requirements of the process. Using cables, the temperature sensor is positioned away from the data logger thermal barrier in the product, preventing the thermal mass of the data logger from affecting the heating characteristics of the product being measured. Unlike systems which require the measurement device to be placed inside the product to protect from the oven temperature, the measurement made by the Multipaq system is an accurate representation of what the product experiences during a normal production run.

Type K	ANSI MC 96.1	±1.1°C (2°F)	0°C to 1250°C	
	Special Limits of Error	±0.4%	(32°F to 2282°F)	
Type T	BS EN 60584.1	±0.5°C (1°F)	-40°C to 350°C	
	Class I	or±0.4%	(-40°F to 662°F)	
Thermocouples supplied in either Type K or Type T				

#### THERMOCOUPLE OPTIONS

#### **MI Needle Probe**

Ambient or product temperature where temperatures exceed 265°C (509°F)

### **Standard Needle**

PTFE cable with insertion probe. Needle length 90 mm (3.5 in), 1.6 mm (.06 in) in diameter. Used to measure internal product temperatures for medium to large products.

#### **Short Needle**

PTFE cable with insertion probe. Needle length 40 mm (1.6 in), 1.6 mm (.06 in) in diameter, with location barb to prevent probe movement. Used to measure internal product temperatures for small to medium-sized products or surface temperatures for large products.

# **Heavy Duty Probe**

PTFE cable with insertion probe. Needle length 125 mm (5 in), 3.2 mm (.12 in) in diameter, with location barb to prevent probe movement and includes a handle to aid with insertion. Used to measure internal product temperatures for large-sized products, typically meat products where probe insertion may be difficult.

# Air Clip Probe

PTFE cable with air temperature sensor mounted on a clip attachment. Used for environmental monitoring of an oven fitted to a product rack or tray used to transport the product.

# **Food Core Probe**

PTFE cable with exposed temperature sensor. Used for environmental monitoring or insertion into products in a semi-solid / liquid state prior to cooking, e.g. bakery.

# **Food Can Probe**

PTFE cable with long round ended needle. Needle length 200 mm (8 in), 1.6 mm (.06 in) in diameter. Used in combination with a can adaptor (PA0620) to measure the internal product temperature of a sealed can / bottle in pasteurization or sterilization processes.



# **TECHNICAL SPECIFICATIONS**

	Type T	Туре К	Barrier Compatibility
DP21 MI Needle Probe	PA I 50(x)	PA151(x)	All
DP21 Food Core Probe	PA 148(x)	PA 149(x)	All
DP21 Air Clip Probe	PA I 54(x)	PA 155(x)	Not TB5814/TB5816
<b>DP21 Short Needle Probe</b>	PA I 44(x)	PA 145(x)	All
DP21 Standard Probe	PA 146(x)	PA I 47(x)	All
DP21 Heavy Duty Probe	PA 142(x)	PA I 47(x)	Not TB5814/TB5815/TB5816
DP21 Food Can Probe	PA 152(x)	PA 153(x)	All
Food Can Adapter	PA0620	PA0620	_

Note: cable length given by last digit (x) of part number 0 = 0.3 m (0.9 ft) 2 = 0.6 m (1.9 ft) 3 = 1.0 m (3.2 ft) 5 = 2.0 m (6.5 ft)

# **USE OF THERMOCOUPLES WITH SUBMERSIBLE BARRIERS**


#### TB5815 / TB5816 / TB5817/TB5016


Fit probe seal appropriate to the cable being used.

To guarantee waterproofing of a barrier in submersible applications, be sure to use the correct probe seal for the probe type being used. Match seal color to the probe type.

#### Probe seal selection













## PA2014 Probe ID tags (bag of 8)

Threaded onto cable to allow easy channel identification during product probing

# **Boil in the bag Patch Probe**

Used to allow insertion of a needle probe via the wall of a bag/pouch without the need to fit connectors inside the bag.

Probe needle is held secure and provides a seal from loss of vacuum or fluid. Bag splitting problems eliminated.

# **PA1700** (bag of 10)

Thermocouple adhesive fixing patch

# PA0620

Can/bottle adaptor



## **Fluke Process Instruments**

#### **EMEA**

Cambridge, UK
Tel: +44 1223 652 400
sales@flukeprocessinstruments.co.uk

#### **Americas**

Salem, NH USA Tel: +1 425 446 6780 sales@flukeprocessinstruments.com

#### China

Beijing, China Tel: +86 10 6438 4691 sales@flukeprocessinstruments.com.cn

#### **Asia East and South**

India Tel: +91 22 2920 7691 Singapore Tel: +65 6799 5596 sales.asia@flukeprocessinstruments.com

#### **Worldwide Service**

Fluke Process Instruments offers services, including repair and calibration. For more information, contact your local office.

# www.flukeprocessinstruments.com

© 2019 Fluke Process Instruments Specifications subject to change without notice. 01/2019 FDT Thermocouples\_DS\_Rev. B1